



SecurityStation supported camera list



Cameras with Plug and Play (PnP) support

Axis

- Axis M3014
- Axis M3113-R
- Axis M3113-VE
- Axis M3203
- Axis M3203-V
- Axis P1343
- Axis P1343-E
- Axis P3301
- Axis P3301-V
- Axis P3343
- Axis P3343-V
- Axis P3343-VE
- Axis P3344
- Axis P3344-V
- Axis P3344-VE

Panasonic

- Panasonic BL-C10
- Panasonic BL-C20
- Panasonic BL-C30
- Panasonic BL-C101
- Panasonic BL-C111
- Panasonic BL-C121
- Panasonic BL-C131
- Panasonic BL-C210
- Panasonic BL-C230
- Panasonic BL-C140
- Panasonic BL-C160
- Panasonic BB-HCM511
- Panasonic BB-HCM531
- Panasonic BB-HCM701
- Panasonic BB-HCM705
- Panasonic BB-HCM715
- Panasonic BB-HCM735
- Panasonic BB-HCM580
- Panasonic BB-HCM581

Additional cameras supported (without Plug and Play)

Axis

- Axis M1011
- Axis M1011-W
- Axis M1031-W
- Axis P3301
- Axis P3301-V

Y-cam

- Y-cam White
- Y-cam White SD
- Y-cam Black
- Y-cam Black SD
- Y-cam Knight
- Y-cam Knight SD
- Y-cam Bullet
- Y-cam Bullet HD

Last updated: 5th March 2012